## **Retractable Banner Stand** CAUTION • This 33" x 80" Vinyl Indoor Banner with stand ships pre-installed. If taken apart to be used with other sizes or materials, it will be at your own risk. · This is not suitable for use in high traffic or confined areas. Inspect both the stand and the banner prior to use. • Do not use if the base and/or pole or other parts show any signs of cracks or damage. • This banner stand is not a toy; it is not intended or suitable for use by children. Extend the telescoping Twist the metal feet out on pole by loosening the the base to support the pole knob, extending the inner and banner. pole then re-tightening the knob. The pole extends to three total sections. Take the stand and pole out of the carrying bag.

Insert the fully extended pole

inside the plastic bracket on

the back of the base.

Fully assembled position.

Hold the top support frame of the banner and gently pull out while placing your foot on the base feet

for additional support. Once out,

plastic support on top of the pole.

slip the metal frame onto the